



SOUND-LIST

Midi-USB-Sound-Modul

BLACKBOX



Y-VERSION

FOR YAMAHA INSTRUMENTS

Yamaha Expansion Manager

My Packs

My Packs

+

>

Instal

Bank Select MSB

Bank Select LSB

063 Normal Voice

039 BB Woodwinds

Program Change

001	Pan Flute1	043	085	127
002	Pan Flute2	044	086	128
003	Pan Flute3	045	087	
004	Pan Flute Att	046	088	
005	Shakuhatchi1	047	089	
006	Shakuhatchi2	048	090	
007	Shakuhatchi3	049	091	
008	SadnessFlute	050	092	
009	Celtic Whistle	051	093	
010	Flute	052	094	
011	Jazz Flute	053	095	
012	Piccolo	054	096	
013	English Horn	055	097	
014	Oboe	056	098	
015	Clarinet Folk	057	099	
016	Clarinet Jazz	058	100	
017	Clarinet Class	059	101	
018	Bass Clarinet	060	102	
019	Whistle	061	103	
020	Bottle Blow	062	104	
021	Basson	063	105	
022	Woodwinds	064	106	
023	Soprano Sax	065	107	
024	Jazzy Sax	066	108	
025	Lounge Sax	067	109	
026	Swing Sax	068	110	
027	Bar Sax	069	111	
028	2nd Alto	070	112	
029	Whisper Sax	071	113	
030	Bariton Sax	072	114	
031	SaxBand1	073	115	
032	SaxBand2	074	116	
033	SaxBand3	075	117	
034	SaxBand4	076	118	
035	SaxBand5	077	119	
036	SaxBand6	078	120	
037	SaxBand7	079	121	
038	Cook Sax1	080	122	
039	Cook Sax2	081	123	
040	Cook Sax3	082	124	
041		083	125	
042		084	126	

Clarinet Class

SaxBand5

Bass Clarinet

SaxBand6

Yamaha Expansion Manager

My Packs

My Packs

+

>

Instal

Edit Program Change

Bank Select MSB

Bank Select LSB

063 Normal Voice

037 BB Strings

Program Change

001	Violine slow	043	Strings&Tromb	085		127	MV_StringsSml
002	Violine	044	Strings&Brass	086		128	MV_StringsUS
003	2 Violins	045	Gladiator Strings	087			
004	Violin&Viola	046	Mumien Strings	088			
005	Viola Quartet	047	Cello	089			
006	Solo&Matrix	048	Contrabass	090			
007	Famous Maratos	049	SynthStrings1	091			
008	White Satin	050	SynthStrings2	092			
009	Mantovani	051	SynthStrings3	093			
010	Movie Strings	052	SynthStrings4	094			
011	Marcato1	053	SynthStrings5	095			
012	Marcato2	054	MatrixStr1	096			
013	Marcato slow	055	MatrixStr2	097			
014	Big Marcato	056	MatrixStr3	098			
015	Spiccato	057	MatrixStr4	099			
016	LargeMarcatos	058	Matrix Slow	100			
017	Large Str1	059	Matrix Dark	101			
018	Large Str2	060	Louvre Strings	102			
019	Large Str3	061	LouvreStrSlow	103			
020	LargeStr1sfz	062		104			
021	LargeStr2sfz	063		105			
022	FastStrings1	064		106			
023	FastStrings2	065		107			
024	FastStrings3	066		108			
025	DiscoStrings1	067		109			
026	DiscoStrings2	068		110			
027	DiscoStrings3	069		111			
028	TremoloStr1	070		112			
029	TremoloStr2	071		113			
030	TremoloSlow1	072		114			
031	TremoloSlow2	073		115			
032	Strings&Horns	074		116			
033	Ensemble1	075		117			
034	60s Strings	076		118			
035	Pizzicato Solo	077		119			
036	PizzicatoEns1	078		120			
037	PizzicatoEns2	079		121			
038	PizzicatoOct	080		122			
039	Pizzagogo1	081		123			
040	Pizzagogo2	082		124			
041	BassPizz	083		125			
042	Orchestra	084		126			

Large Str1

Pizzicato Solo

SynthStrings1

Large Str2

PizzicatoEns1

MatrixStr1

Yamaha Expansion Manager

My Packs

My Packs

+

>

Install

063 Normal Voice

042 BB Pads

Program Change

001	The Air Pad	043	Itopia Pad	085	127
002	Wanna Know	044	Bowed Pad1	086	128
003	MegaPad1	045	Bowed Pad2	087	
004	MegaPad2	046	Whale Pad	088	
005	MegaSawPad	047	Metallic Pd1	089	
006	HPResoPad1	048	Metallic Pd2	090	
007	HPResoPad2	049	PanPad1	091	
008	HPResoPad3	050	PanPad2	092	
009	HPResoPad4	051	HaloPad1	093	
010	LPResoPad1	052	HaloPad2	094	
011	LPResoPad2	053	HaloPad3	095	
012	LPResoPad3	054	SweepPad1	096	
013	LPResoPad4	055	SweepPad2	097	
014	HP-LP Pad	056	DipolarPad	098	
015	GigaPad1	057	Rising	099	
016	GigaPad2	058	Rain Heaven	100	
017	D50 NativeDance1	059	Atmosphere1	101	
018	D50 NativeDance2	060	Atmosphere2	102	
019	D50 NativePad1	061	Warm Air	103	
020	D50 NativePad2	062	Brightness	104	
021	D50 NativePad3	063	NewYearPad	105	
022	D50 NativePad4	064		106	
023	D50 NativePad5	065		107	
024	D50 NativePad6	066		108	
025	D50 Chorale	067		109	
026	D55 Pad	068		110	
027	FM Pad1	069		111	
028	FM Pad2	070		112	
029	NewAgePad1	071		113	
030	NewAgePad2	072		114	
031	NewAgePad3	073		115	
032	NewAgePad4	074		116	
033	Warm Pad1	075		117	
034	Warm Pad2	076		118	
035	Sinus Pad	077		119	
036	PWM Pad	078		120	
037	Warmly Pad	079		121	
038	Horn Pad	080		122	
039	Click Pad	081		123	
040	Analog Pad	082		124	
041	Poly Pad	083		125	
042	Choir Pad	084		126	

Yamaha Expansion Manager

My Packs

My Packs

+

>

⚙

ℹ

Install

Get

PS

PS

PS

TV

Edit Program Change

Bank Select MSB

063 Normal Voice

Bank Select LSB

034 BB Organ WE

Program Change

001	HE Low Drwbs	043	Spec-Full6	085	Sat WVN 1-13'	127	KlausBass 8'
002	HE Low DrwbsP	044	Spec-Full1 drk	086	Sat WVN 1'	128	KlausBass 16&8'
003	HE LowMid Drw	045	Spec-Full2 drk	087	WVN 880000000		
004	HE Mid Drwbs	046	Spec-Ultra1	088	WVN 888000000		
005	HE Hi Drwbs	047	Spec-Ultra2	089	WVN 800000006		
006	HE Mixt1	048	Spec-Ultra3	090	WVN 880808008		
007	HE Mixt2	049	Spec Trumpet1	091	WVN 880800000		
008	HE Mixt3	050	Spec Trumpet2	092	WVN 880080000		
009	HE Mixt4	051	Spec Brass1	093	WVN 880008000		
010	HE Full1	052	Spec Brass2	094	WVN 800800000		
011	HE Full2	053	Spec Brass3	095	WVN 888800000		
012	HE Perc4'	054	Spec Brass4	096	WVN 080680860		
013	HE Perc2-23'	055	Comet Git1	097	WVN 080600000		
014	HE Perc2'	056	Comet Git2	098	WVN 080400006		
015	HE Patch	057	Comet Git vib	099	WVN 080450006		
016	HE Strings1	058	Beta Perc1	100	WVN 080867000		
017	HE Strings2	059	Beta Perc2	101	Klaus Percussion4		
018	HE Strings3	060	Beta Perc3	102			
019	HE Trumpet1	061	Soli-Strings1	103			
020	HE Trumpet2	062	Soli-Strings2	104			
021	HE Trumpet3	063	Soli-Strings3	105			
022	HE Flute	064	Soli-Strings4	106			
023	Klaus sein Sax	065	Soli-StringsUltra	107			
024	HE Trombone1	066	HE-JuStr1	108			
025	HE Trombone2	067	HE-JuStr2	109			
026	HE Trombone3	068	HE-JuStr3	110			
027	HE Klarinette1	069	HE-JuStr4	111			
028	HE Klarinette2	070	JuStr1	112			
029	HE Oboe	071	JuStr2	113			
030	HE PanFlute	072	JuSoli1	114			
031	HE TrombWah1	073	JuSoli2	115			
032	HE TrombWah2	074	Klaus Percussion1	116			
033	HE Piano	075	Klaus Percussion2	117			
034	HE Pianostar	076	Klaus Percussion3	118			
035	HE HonkyTonk	077	HE Spinett	119			
036	HE Banjo	078	Sat WVN 16'	120			
037	HE Musette	079	Sat WVN 8'	121			
038	Spec-Full1	080	Sat WVN 5-13'	122			
039	Spec-Full2	081	Sat WVN 4'	123			
040	Spec-Full3	082	Sat WVN 2-23'	124	BassGitarre1		
041	Spec-Full4	083	Sat WVN 2'	125	BassGitarre2		
042	Spec-Full5	084	Sat WVN 1-35'	126	KlausBass 16'		

Klaus Percussion4

WVN 880080000

Spec-Ultra1

HE PanFlute

Soli-Strings1

Klaus Percussion4

WVN 880080000

Spec-Ultra2

HE TrombWah1

Soli-Strings2

Yamaha Expansion Manager

My Packs

My Packs

+

>

Instal

063 Normal Voice

044 BB Organ various

Edit Program Change

Program Change

001	60s Organ1	043	085	127
002	60s Organ2	044	086	128
003	60s Organ3	045	087	
004	60s Organ4	046	088	
005	60s Organ5	047	089	
006	60s Organ6	048	090	
007	60s Organ7	049	091	
008	Ital. Organ1	050	092	
009	60sOrgan223	051	093	
010	60sOrgan135	052	094	
011	Barrel Organ	053	095	
012		054	096	
013		055	097	
014		056	098	
015		057	099	
016		058	100	
017		059	101	
018		060	102	
019		061	103	
020		062	104	
021		063	105	
022		064	106	
023		065	107	
024		066	108	
025		067	109	
026		068	110	
027		069	111	
028		070	112	
029		071	113	
030		072	114	
031		073	115	
032		074	116	
033		075	117	
034		076	118	
035		077	119	
036		078	120	
037		079	121	
038		080	122	
039		081	123	
040		082	124	
041		083	125	
042		084	126	



Bank Select MSB

Bank Select LSB

063 Normal Voice ▼ 035 BB Organ Theatre

Program Change

001	LC Glockenspiel	043	085	127
002	Tibia 8' NT	044	086	128
003	Tibia 8'	045	087	
004	OpenFlute NT	046	088	
005	OpenFlute	047	089	
006	VoxHumanaNT	048	090	
007	VoxHumana	049	091	
008	OrchOboeNT	050	092	
009	OrchOboe	051	093	
010	Viol d'OrchNT	052	094	
011	Viol d'Orch	053	095	
012	Xylophone	054	096	
013		055	097	
014		056	098	
015		057	099	
016		058	100	
017		059	101	
018		060	102	
019		061	103	
020		062	104	
021		063	105	
022		064	106	
023		065	107	
024		066	108	
025		067	109	
026		068	110	
027		069	111	
028		070	112	
029		071	113	
030		072	114	
031		073	115	
032		074	116	
033		075	117	
034		076	118	
035		077	119	
036		078	120	
037		079	121	
038		080	122	
039		081	123	
040		082	124	
041		083	125	
042		084	126	

Yamaha Expansion Manager

My Packs

My Packs

+>

⚙️ ⓘ

Install

Program Change

063 Normal Voice

033 BB Organ HA

Bank Select MSB

Bank Select LSB

Program Change

001	HA Low Drw	043	B3 Full FS drk	085	127
002	HA Low Drw cl	044	Bright Drawbar1	086	128
003	HA Mid Drw	045	Bright Drawbar2	087	
004	HA Hi Drw	046	70s PercOrg1	088	
005	HA Mixt1	047	70s PercOrg2	089	
006	HA Mixt2	048	70s PercOrg3	090	
007	HA Full	049	70s PercOrg4	091	
008	HA Perc4'	050	H Glock	092	
009	HA Perc223'	051	H Marimba	093	
010	HA Perc2'	052	H Xylophon	094	
011	HA Perc4' sh	053	H Guitar	095	
012	HA Perc223' sh	054	H Banjo	096	
013	HA Perc2' sh	055	H Glock shrt	097	
014	HA Click	056	H Marimba shrt	098	
015	HA Low Rock	057	H Xylophon shrt	099	
016	B3 Low C3 vib	058	H Guitar shrt	100	
017	B3 2nd	059	H Banjo shrt	101	
018	B3 3rd	060	CimbalonVOX	102	
019	Jimmy Jazz 3rd	061	60's Perc4'	103	
020	Jimmy Jazz 2nd	062	60's Perc223'	104	
021	B3 16' cl	063	70's Perc4'	105	
022	B3 16'	064	70's Perc223'	106	
023	B3 513'	065	H100 Mixt1 LS	107	
024	B3 8'	066	H100 Mixt2 LS	108	
025	B3 4'	067	Aurora P2	109	
026	B3 223'	068	B3 808000000	110	
027	B3 2'	069	B3 808800000	111	
028	B3 135'	070	B3 2nd short	112	
029	B3 113'	071	B3 3rd short	113	
030	B3 1'	072	B3 Perc 2'	114	
031	B3 888000000 cl	073		115	
032	B3 888000000	074		116	
033	B3 888000000 2nd	075		117	
034	B3 800000004	076		118	
035	B3 800000854	077		119	
036	B3 800080000	078		120	
037	B3 008080000	079		121	
038	B3 008600000	080		122	
039	B3 004161432	081		123	
040	B3 008630000	082		124	
041	B3 808808008	083		125	
042	B3 Full FS	084		126	

HA Low Rock

B3 1

Aurora P2

70's Perc223'

B3 Low C3 vib

B3 888000000 cl

70s PercOrg1

CimbalonVOX

Yamaha Expansion Manager

My Packs

My Packs

+>

⚙️ ⓘ

Install

General

Program Set

Program Set

Program Set

Timbre

Edit Program Change

Bank Select MSB

063 Normal Voice

Bank Select LSB

040 BB Bells-Mallet

Program Change

001	Vibraphone	043	085	127
002	SA Vibes	044	086	128
003	SA Vibes Stereo	045	087	
004	DX TubeBells	046	088	
005	Tubular Bells	047	089	
006	Carrillion	048	090	
007	Steel Drums	049	091	
008	Athen Bells	050	092	
009	SA Fantasia	051	093	
010	Marimba	052	094	
011	Marimba Rep	053	095	
012	Xylophone	054	096	
013	Xylophone Rep	055	097	
014	Bell-Pad1	056	098	
015	Bell-Pad2	057	099	
016	Bell-Pad3	058	100	
017	Bell-Pad4	059	101	
018	Bell-Pad5	060	102	
019	Bell-Pad6	061	103	
020	Bell-Pad7	062	104	
021	Bell-Pad8	063	105	
022	Bell-Pad9	064	106	
023	Bell-Pad10	065	107	
024	Bell-Pad11	066	108	
025	Mixed- Bells1	067	109	
026	Mixed- Bells2	068	110	
027	Mixed- Bells3	069	111	
028	Mixed- Bells4	070	112	
029	Mixed- Bells5	071	113	
030	Mirror Bell	072	114	
031	MusicBox	073	115	
032	Glockenspiel	074	116	
033	Celesta	075	117	
034	SynBell1	076	118	
035	SynBell2	077	119	
036	SynBell3	078	120	
037	Tinkle Bell1	079	121	
038		080	122	
039		081	123	
040		082	124	
041		083	125	
042		084	126	

Bell-Pad4

SynBell2

Bell-Pad5

SynBell3

Yamaha Expansion Manager

My Packs

My Packs

+

>

⚙

ℹ

Install

063 Normal Voice

043 BB Lead Synth

Program Change

001	Female Lead	043	JP Sine Solo	085	Rhy_Synth07	127
002	MegaSynth	044	Popcorn	086	Rhy_Synth08	128
003	90s Saw1	045	2OszLead	087	Rhy_Synth09	
004	90s Saw2	046	JP Puls Solo	088	Rhy_Synth10	
005	90s Saw3	047	Funny1	089	Rhy_Synth11	
006	90s Saw4	048	Funny2	090	Plucked Lead	
007	90s Dance1	049	Funny3	091	PluckedLd&Str	
008	90s Dance2	050	Funny4	092	Shaped Pluck	
009	90s Dance3	051	Funny5	093	CutVoice	
010	90s Saw1 HP	052	JP Lead1	094	Andy'sPluck1	
011	90s Saw2 HP	053	JP Lead2	095	Andy'sPluck2	
012	90s TechnoStab1	054	JP Lead3	096	Andy'sPluck3	
013	90s TechnoStab2	055	PulseLead1	097	Andy'sPluck4	
014	90s Technolot	056	PulseLead2	098	PluckSinus1	
015	90s MasterSaw1	057	PulseLead3	099	PluckSinus2	
016	90s MasterSaw2	058	PulseLead4	100	PluckSinus3	
017	90s VainSaw1	059	PulseLead5	101	Juno Marimba	
018	90s VainSaw2	060	Pulsar	102	Juno Pluck	
019	90s VainSaw3	061	Cartoon Jump	103		
020	00s DanceSynth1	062	SinusLead1	104		
021	00s DanceSynth2	063	SinusLead2	105		
022	00s DanceSynth3	064	PanaramaLead	106		
023	00s DanceSynth4	065	SquareClean	107		
024	1980f	066	Sawtooth1	108		
025	P5 Sync1	067	Sawtooth2	109		
026	P5 Sync2	068	Saw&Puls	110		
027	P5 Sync3	069	Double Saw	111		
028	P5 Sync4	070	Big Lead	112		
029	Real Life	071	DoubleLead	113		
030	Dancing Tears	072	FilterModLead	114		
031	Shamus1	073	PolySynth1	115		
032	Shamus2	074	PolySynth2	116		
033	LiquidStack1	075	PolySynth3	117		
034	LiquidStack2	076	Liq Lead	118		
035	LiquidStack3	077	Just Can't	119		
036	LiquidStack4	078	Laserharp	120		
037	SquareLead1	079	Rhy_Synth01	121		
038	SquareLead2	080	Rhy_Synth02	122		
039	SquareLead3	081	Rhy_Synth03	123		
040	SquareLead4	082	Rhy_Synth04	124		
041	SlowSquare	083	Rhy_Synth05	125		
042	ThickSquare	084	Rhy_Synth06	126		

90s VainSaw1

LiquidStack3

JP Lead2

DoubleLead

Rhy_Synth11

90s VainSaw2

LiquidStack4

JP Lead3

FilterModLead

Plucked Lead

Yamaha Expansion Manager

My Packs

My Packs

+

>

⚙️

ℹ️

Install

Program Change

Bank Select MSB

063 Normal Voice

Bank Select LSB

041 BB Guitars

001	MandolinTrem	043	OberkFX Git08	085	127
002	MandolinEns1	044	OberkFX Git09	086	128
003	MandolinEns2	045	OberkFX Git10	087	
004	SpanishGtr1	046	OberkFX Git11	088	
005	SpanishGtr2	047	OberkFX 1	089	
006	SpanishGtr3	048	OberkFX 2	090	
007	SpanishGtr4	049	OberkFX 3	091	
008	SteelGtr1	050	OberkFX 4	092	
009	SteelGtr2	051	CleanFunkyHi1	093	
010	SteelGtr3	052	CleanFunkyHi2	094	
011	SteelBrit1	053	CleanFunkyHi3	095	
012	SteelBrit2	054	CleanFunkyMd1	096	
013	FolkGtr	055	CleanFunkyMd2	097	
014	12 StrGtr1	056	CleanFunkyMd3	098	
015	12 StrGtr2	057	CleanFunkyMd4	099	
016	12 StrGtr3	058	CleanFunkyMd5	100	
017	Clean Git1	059	CleanFunkyMd6	101	
018	Clean Git2	060	CleanFunkyMd7	102	
019	Clean Git3	061	FunkyGtrFX	103	
020	Clean Chorus	062	AcGtrFX	104	
021	MidToneGtr	063	Mute Gtr1	105	
022	CleanOverd1	064	Mute Gtr2	106	
023	CleanOverd2	065	Mute Gtr3	107	
024	DX-7 Guitar	066	Mute Gtr4	108	
025	Oberk Git01	067	Mute Gtr5	109	
026	Oberk Git02	068	DanceGit1	110	
027	Oberk Git03	069	DanceGit2	111	
028	Oberk Git04	070	DanceGit3	112	
029	Oberk Git05	071	DanceGit4	113	
030	Oberk Git06	072	CountrySlide1	114	
031	Oberk Git07	073	CountrySlide2	115	
032	Oberk Git08	074	CountrySlide3	116	
033	Oberk Git09	075	CountrySlide4	117	
034	Oberk Git10	076	Cimbalon	118	
035	Oberk Git11	077	Spanish slide	119	
036	OberkFX Git01	078	60s Guitar1	120	
037	OberkFX Git02	079	60s Guitar2	121	
038	OberkFX Git03	080	60s Guitar3	122	
039	OberkFX Git04	081	JazzGuitar	123	
040	OberkFX Git05	082	JazzGuitar slide	124	
041	OberkFX Git06	083	Cimbalon vel	125	
042	OberkFX Git07	084	Cimbalon Trem	126	

12 StrGtr3

Mute Gtr3

Oberk Git07

OberkFX 3

60s Guitar1

CountrySlide1

Oberk Git08

OberkFX 4

Yamaha Expansion Manager

My Packs

My Packs

+

>

Instal

Edit Program Change

Bank Select MSB

Bank Select LSB

063 Normal Voice

032 BB Elec.Piano

Program Change

001	Suitcase1	043	Wah Clavinet2	085	127
002	Suitcase2	044	Wah Clavinet3	086	128
003	MK-1	045		087	
004	Rhodes 73	046		088	
005	FeRhodes1	047		089	
006	Riders Trem FR	048		090	
007	Funk EP	049		091	
008	Wurly	050		092	
009	Wurly Trem	051		093	
010	Wurly wide	052		094	
011	Classic FM	053		095	
012	BellRose1	054		096	
013	BellRose2	055		097	
014	BellRoseAtt	056		098	
015	Brite Bell	057		099	
016	Brite Bell Att	058		100	
017	JD Crystal EP1	059		101	
018	JD Crystal EP2	060		102	
019	DX EP1	061		103	
020	DX EP2	062		104	
021	DX EP3	063		105	
022	DX EP4	064		106	
023	DX EP5	065		107	
024	DX EP6	066		108	
025	DX EP7	067		109	
026	DX EP8	068		110	
027	GS Dancer	069		111	
028	GS Dancer sft	070		112	
029	EP Bright1	071		113	
030	EP Bright2	072		114	
031	EP Bell1	073		115	
032	EP Bell2	074		116	
033	EP Bell3	075		117	
034	EP Bell4	076		118	
035	SAEP1_1	077		119	
036	SAEP1_2	078		120	
037	SAEP2_1	079		121	
038	SAEP2_2	080		122	
039	Deebach EP1	081		123	
040	Clavinet1	082		124	
041	Clavinet2	083		125	
042	Wah Clavinet1	084		126	

JD Crystal EP1

SAEP1_1

Yamaha Expansion Manager

My Packs

My Packs

+

>

⚙

ℹ

Install

General

Pack Selection

Pack Selection

Pack Selection

Pack Selection

Tools

Edit Program Change

Bank Select MSB

063 Normal Voice

Bank Select LSB

051 BB Drums-FX

Program Change

001	Dance Bongos1	043	EDM Break SD	085		127	WM2
002	Dance Bongos2	044	Miami Timbales	086		128	XG StndKit1
003	Dance Bongos3	045	Timpani1	087			
004	TribalBreak1	046	Timpani2	088			
005	TribalBreak2	047	Timpani3	089			
006	TribalBreak3	048	Timpani&CR	090			
007	TaikoDrum1	049	SD99 rev1	091			
008	TaikoDrum2	050	SD99 rev2	092			
009	Chinese Gong	051	SD99 rev3	093			
010	AgogoBells1	052	SD99 rev4	094			
011	AgogoBells2	053	SD88 rev1	095			
012	CowBell88	054	SD88 rev2	096			
013	ConcertBD1	055	Clap 99	097			
014	ConcertBD2	056	Clap 88	098			
015	ConBD&CR1	057	L1 Clap	099			
016	ConBD&CR2	058	L1 Conga	100			
017	MelodicTom	059	RevCymbal1	101			
018	PwrMelTom	060	RevCymbal2	102			
019	Rodger'sTom1	061	RevCymbal3	103			
020	Rodger'sTom2	062	RevCymbal4	104			
021	Rodger'sTom3	063	RevKick1	105			
022	Rodger'sTom4	064	RevKick2	106			
023	Roto Toms	065	RevHigh Q	107			
024	66 Toms	066	Kick&CR1	108			
025	DanceToms2020	067	Kick&CR2	109			
026	SimToms1	068	Kick&CR3	110			
027	SimToms2	069	Crash1	111			
028	SimToms3	070	Crash2	112			
029	70sSynthDr1	071	SubBomb	113			
030	70sSynthDr2	072	WhiteNoiseCymb	114			
031	70sSynthDr3	073	NoiseSweep1	115			
032	70sSynthDr4	074	NoiseSweep2	116			
033	PWL Toms	075	NoiseSweep3	117			
034	Rev Toms1	076		118			
035	Rev Toms2	077		119			
036	Rev Toms3	078		120			
037	SD99 1	079		121			
038	SD99 2	080		122			
039	SD99 3	081		123			
040	SD99 4	082		124	CR Kit		
041	SD88 1	083		125	MP-7		
042	SD88 2	084		126	RhyAce		

MelodicTom

Rev Toms2

SD99 rev1

SubBomb

PwrMelTom

Rev Toms3

SD88 rev2

WhiteNoiseCymb

Yamaha Expansion Manager

My Packs

My Packs

+>

⚙️ ⓘ

Install

062 Drum Voice

Bank Select LSB

000 BB Drum Kits

Program Change

001	Stand GM 1	043	P24	085	127
002	Stand 60s	044	Analog Party	086	128
003	Stand 80s 1	045	Analog1	087	
004	Stand 80s 2	046	Analog2	088	
005	Stand GM 2	047	Funk	089	
006	Stand GM 3	048	Latin	090	
007	Stand GM 4	049	Vintage Rock	091	
008	Brush Xg	050	Rock	092	
009	Power1	051	Power2	093	
010	Volksmusik	052	Electro1	094	
011	Pop-Schlager1	053	Electro2	095	
012	Pop-Schlager2	054	ModernBrush	096	
013	Pop-Schlager3	055	LiveBrush	097	
014	Nu-Schlager	056	Percussion	098	
015	Dolphine Kit	057	BD's	099	
016	Nu-Disco	058	SD's	100	
017	EDM	059	HitKit Xg	101	
018	Deep House	060	Room Xg	102	
019	2000s Dance	061	Rock Xg	103	
020	Reggae-Ton	062	Electro XG	104	
021	Soul	063	Analog Xg	105	
022	90s Dance	064	Dance Xg	106	
023	90s Special	065	Jazz Xg	107	
024	90s Pop	066	Symphony Xg	108	
025	80s Pop1	067	House Xg	109	
026	80s Pop2	068	Power Xg	110	
027	80s Pop3	069	Pop Latin	111	
028	80s Rock1	070		112	
029	80s Rock2	071		113	
030	80s Rock3	072		114	
031	80s Spezial1	073		115	
032	80s Spezial2	074		116	
033	Phill's Drums1	075		117	
034	Phill's Drums2	076		118	
035	80s Dance1	077		119	
036	80s Dance2	078		120	
037	Electronic66	079		121	
038	WM2	080		122	
039	VL-1	081		123	
040	Rodger'sDrums	082		124	
041	DMX	083		125	
042	KR-55+	084		126	

Deep House

80s Dance2

ModernBrush

Yamaha Expansion Manager

My Packs

My Packs

+

>

Instal

001 CuttingVoices1

002 CuttingVoices2

003 CuttingVoices3

004 80sChoir1

005 80sChoir2

006 80sChoir3

007 80sChoir4

008 M1 Univers1

009 M1 Univers2

010 Choir Aah1

011 Choir Aah2

012 Choir Aah3

013 Choir Aah4

014 Choir Aah mellow

015 Choir Aah wide

016 Choir&String1

017 Choir&String2

018 Choir Ooh

019 Humming

020 ArrChoir

021 Hallelujah1

022 Hallelujah2

023 80sChoirString1

024 80sChoirString2

025 80sChoirBell

026

027

028

029

030

031

032

033

034

035

036

037

038

039

040

041

042

043

044

045

046

047

048

049

050

051

052

053

054

055

056

057

058

059

060

061

062

063

064

065

066

067

068

069

070

071

072

073

074

075

076

077

078

079

080

081

082

083

084

085

086

087

088

089

090

091

092

093

094

095

096

097

098

099

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

063 Normal Voice

045 BB Choir

Program Change

Yamaha Expansion Manager

My Packs

My Packs

+

>

Install

001

002

003

004

005

006

007

008

009

010

011

012

013

014

015

016

017

018

019

020

021

022

023

024

025

026

027

028

029

030

031

032

033

034

035

036

037

038

039

040

041

042

Program Change

001 Solo Trumpet1

002 Solo Trumpet2

003 Solo Trumpet3

004 Jazz Trumpet Hi

005 DarkTrumpet

006 Wah Trumpet1

007 2 Trumpets

008 3 Trumpets

009 3 Trumpets Loose

010 FluegelHorn1

011 FluegelHorn2

012 FluegelHorn Pro

013 FluegelHorn sft

014 Bright Trombone

015 Trombone vib

016 Dark Trombone

017 2 Trombones

018 BrassSection1

019 BrassSection2

020 BrassSection3

021 BrassSection4

022 BrassSection5

023 BrassSection6

024 SfzBrass slw

025 SfzBrass fst

026 BalladBrass1

027 BalladBrass2

028 BalladBrass3

029 BalladBrass4

030 BalladBrass5

031 Brass&Mute

032 Bari&Horns1

033 Bari&Horns2

034 Bari&Horns3

035 DX Brass

036 French Horn1

037 French Horn2

038 French Horn3

039 Tenor Horns

040 French HornSec1

041 French HornSec2

042 Bariton

Bank Select MSB

063 Normal Voice

Bank Select LSB

038 BB Brass

043 Bariton&Bass1

044 Bariton&Bass2

045 MuteTrumpet1

046 MuteTrumpet2

047 MuteTrumpet3

048 MuteTrumpet4

049 Wah Trumpet2

050

051

052

053

054

055

056

057

058

059

060

061

062

063

064

065

066

067

068

069

070

071

072

073

074

075

076

077

078

079

080

081

082

083

084

085

086

087

088

089

090

091

092

093

094

095

096

097

098

099

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

FluegelHorn Pro

BalladBrass5

FluegelHorn sft

Brass&Mute

Yamaha Expansion Manager

My Packs

My Packs

+

>

⚙️

ℹ️

Install

Program Change

Bank Select MSB

Bank Select LSB

063 Normal Voice

049 BB Bass

001	Ac.Bass1	043	ItaloBass4	085	PulseBass7	127
002	Ac.Bass2	044	ItaloBass5	086	PulseDistBs	128 MV_Elec.Bass1
003	Ac.Bs Ride	045	P24BassGuitar	087	MG SynBs1	
004	Rockabilly Bs	046	P24DoubleBs	088	MG SynBs2	
005	Bert's Bass	047	P24Tuba	089	BassdeMusic	
006	Fing.Bass1	048	HouseBass1	090	LowSinusBs1	
007	Fing.Bass2	049	HouseBass2	091	LowSinusBs2	
008	Fing.Bass3	050	HouseBass3	092	LowSinusBs3	
009	Fing.Bass4	051	HouseBass4	093	LowSinusBs4	
010	StingerBass1	052	HouseBass5	094	SubBass1	
011	StingerBass2	053	DeepHouseBs1	095	SubBass2	
012	DarkStingerBs	054	DeepHouseBs2	096	SubBass3	
013	FingSlap1	055	DeepHouseBs3	097	SubBass4	
014	FingSlap2	056	80sDXBass1	098	SubBass5	
015	70sDiscoBs	057	80sDXBass2	099	SubBass6	
016	PickBass1	058	80sDXBass3	100	SubBass7	
017	PickBass2	059	90sDxBass	101	SubBass8	
018	RockPickBs	060	PumpBass	102		
019	MutePickBs	061	VainBass1	103		
020	DetPickBs	062	VainBass2	104		
021	FretlessBs1	063	Michis'sBass	105		
022	FretlessBs2	064	EDM Bass1	106		
023	FretlessBs3	065	EDM Bass2	107		
024	DetFretless1	066	EDM Bass3	108		
025	DetFretless2	067	EDM Bass4	109		
026	DetFretless3	068	EDM Bass5	110		
027	SlapBass1	069	EDM Bass6	111		
028	SlapBass2	070	EDM Bass7	112		
029	SynthBass1	071	EDM Bass8	113		
030	SynthBass2	072	EDM Bass9	114		
031	SynthBass3	073	EDM Bass10	115		
032	SynthBass4	074	EDM Bass11	116		
033	SynthBass5	075	Hand'sUpBass	117		
034	SynthBass6	076	LatelyBass	118		
035	WarmSynBs1	077	FB Mono Bass	119		
036	WarmSynBs2	078	AttackPulseBs	120		
037	ResoSynBs1	079	PulseBass1	121		
038	ResoSynBs2	080	PulseBass2	122		
039	ResoSynBs3	081	PulseBass3	123		
040	ItaloBass1	082	PulseBass4	124		
041	ItaloBass2	083	PulseBass5	125		
042	ItaloBass3	084	PulseBass6	126		

PickBass2

WarmSynBs1

DeepHouseBs1

EDM Bass0

BassdeMusic

RockPickBs

WarmSynBs2

DeepHouseBs2

EDM Bass9

LowSinusBs1

Yamaha Expansion Manager

My Packs

My Packs

+

>

✖

Edit Program Change

Bank Select MSB

Bank Select LSB

063 Normal Voice

031 BB Ac.Piano

Program Change

001	Deebach Grand1	043	Oct Piano2	085	127
002	Classic Grand1	044		086	128
003	Classic Grand2	045		087	
004	Swedish Grand	046		088	
005	Pop Grand1	047		089	
006	Pop Grand2	048		090	
007	Pop Grand3	049		091	
008	Pop Grand4	050		092	
009	Pop Grand5	051		093	
010	Pop Grand6	052		094	
011	Kaw Upright1	053		095	
012	Kaw Upright2	054		096	
013	Kaw Upright3	055		097	
014	Kaw Upright4	056		098	
015	CP Grand1	057		099	
016	CP Grand2	058		100	
017	CP Grand3	059		101	
018	CP Grand4	060		102	
019	Sharp Piano1	061		103	
020	Sharp Piano2	062		104	
021	Sharp Piano3	063		105	
022	Old Grand1	064		106	
023	Old Grand2	065		107	
024	Old Grand3	066		108	
025	Rock Grand1	067		109	
026	Rock Grand2	068		110	
027	Italien Grand	069		111	
028	SA Piano3 St	070		112	
029	SA Piano3 sft	071		113	
030	SA Piano3 wide	072		114	
031	M1-Piano	073		115	
032	M1-Piano wide	074		116	
033	Harpsichord	075		117	
034	Harpsichord wide	076		118	
035	Harpsichord Oct	077		119	
036	Harpsichord2	078		120	
037	Piano-Strings1	079		121	
038	Piano-Strings2	080		122	
039	Piano-Pad	081		123	
040	Piano-Choir	082		124	
041	Piano-Vibes	083		125	
042	Oct Piano1	084		126	

CP Grand1

Harpsichord

CP Grand2

Harpsichord wide

Yamaha Expansion Manager

My Packs

My Packs

+

>

⚙

ℹ

Install

General

Pack

Pack

Pack

TV

Edit Program Change

Bank Select MSB

063 Normal Voice

Bank Select LSB

036 BB Accordion

Program Change

001	Holland Acc1	043	085	127
002	Holland Acc2	044	086	128
003	Italian Acc	045	087	
004	James Acc1	046	088	
005	James Acc2	047	089	
006	James Acc3	048	090	
007	Hamburg Acc	049	091	
008	Russian Acc1	050	092	
009	Russian Acc2	051	093	
010	Alpin Acc	052	094	
011	Oberk. Acc	053	095	
012	Musette1	054	096	
013	Musette2	055	097	
014	Musette3	056	098	
015	Musette4	057	099	
016	Musette5	058	100	
017	German Acc	059	101	
018	Steirisch1	060	102	
019	Steirisch2	061	103	
020	Tango Acc1	062	104	
021	Tango Acc2	063	105	
022	Tango Acc3	064	106	
023	Melodica	065	107	
024	Harmonica1	066	108	
025	Harmonica2	067	109	
026	Harmonica Folk	068	110	
027	CRock Trem	069	111	
028	CRock Harm	070	112	
029	CRock Blues	071	113	
030		072	114	
031		073	115	
032		074	116	
033		075	117	
034		076	118	
035		077	119	
036		078	120	
037		079	121	
038		080	122	
039		081	123	
040		082	124	
041		083	125	
042		084	126	

German Acc

Steirisch1