

No.	MS B	LSB	Pro.	Name
1	121	0	0	Classic Grand1
2	121	0	0	Classic Grand1 Ch
3	121	3	0	Classic Grand2
4	121	3	0	Classic Grand2 CH
5	121	0	1	Pop Grand1
6	121	0	1	Pop Grand1 Ch
7	121	5	1	Pop Grand2
8	121	5	1	Pop Grand2 CH
9	121	7	1	Pop Grand3
10	121	7	1	Pop Grand3 CH
11	121	9	1	Pop Grand4
12	121	9	1	Pop Grand4 CH
13	121	11	1	Pop Grand5
14	121	11	1	Pop Grand5
15	121	23	1	Pop Grand6
16	121	23	1	Pop Grand6
17	121	6	1	ClassicPop
18	121	0	2	CP Grand1
19	121	0	2	CP Grand1 Ch
20	121	2	2	CP Grand2
21	121	2	2	CP Grand2 Ch
22	121	3	2	CP Grand3
23	121	3	2	CP Grand3 Ch
24	121	4	2	CP Grand4
25	121	4	2	CP Grand4 Ch
26	121	1	2	CP Grand wide
27	121	1	2	CP Grand wide Ch
28	121	10	2	Elec.Grand drk
29	121	10	2	Elec.Grand drk Ch
30	121	1	0	Grand Piano wide
31	121	2	0	Classic Grand drk
32	121	1	1	Bright Piano wide
33	121	11	0	Octave Piano1

**LUNA** Sounds 1.08a



34	121	12	0	Octave Piano2
35	121	13	0	Mono Grand1
36	121	14	0	Mono Grand2
37	121	15	0	John's Piano
38	121	10	1	Jazz Upright
39	121	10	0	Rock Grand1
40	121	10	0	Rock Grand1 CH
41	121	12	1	Rock Grand2
42	121	12	1	Rock Grand2 CH
43	121	0	3	Honky Tonk
44	121	1	3	Honky Tonk wide
45	121	2	3	Honky Tonk bright
46	121	3	3	Old Grand Piano1
47	121	4	3	Old Grand Piano2
48	121	5	3	Old Grand Piano3
49	121	10	3	Honky Tonk/Dark
50	121	11	3	Honky Tonk/Stereo
51	121	120	1	Reverse Piano1
52	121	121	1	Reverse Piano2
53	121	2	1	SA Piano3
54	121	3	1	SA Piano3 St
55	121	4	1	SA Piano3 soft
56	121	8	1	SA Piano3 FX
57	121	20	1	M1 Piano
58	121	20	1	M1 Piano FX
59	121	19	1	M1 Piano detun1
60	121	11	2	Fusion Piano
61	121	13	1	Club Piano1
62	121	12	2	Club Piano2
63	121	13	2	Wah Piano
64	121	21	4	Digital Piano
65	121	0	6	Harpsichord1
66	121	1	6	Harpsichord Oct
67	121	2	6	Harpsichord wide
68	121	3	6	Harpsichord2



69	121	10	6	Analog Harpsi
70	121	16	0	Piano&EP1
71	121	17	1	Piano&EP2
72	121	21	0	Piano&Strings1
73	121	14	1	Piano&Strings2
74	121	15	1	Piano&Pad
75	121	16	1	Piano&Choir
76	121	17	0	Piano&Vibra1
77	121	18	1	Piano&Vibra2
78	121	21	1	Piano&Calliope
79	121	22	1	Piano&Sweep
80	121	20	4	EP&Strings1
81	121	16	5	EP&Strings2
82	121	18	4	Choir EP1
83	121	14	5	Choir EP2
84	121	22	4	E.Piano&Pad1
85	121	21	5	E.Piano&Pad2
86	121	23	4	E.Piano&Sweep1
87	121	22	5	E.Piano&Sweep2
88	121	23	5	E.Piano2&WarmPad
89	121	21	6	Harpsichord&StStr
90	121	0	4	FeRho Piano1
91	121	0	4	FeRho Piano1 Ch
92	121	28	4	FeRho Piano2
93	121	28	4	FeRho Piano2 Ch
94	121	29	4	FeRho Piano3
95	121	29	4	FeRho Piano3 Ch
96	121	30	4	FeRho Piano4
97	121	30	4	FeRho Piano4 Ch
98	121	3	4	Wurly EP1
99	121	3	4	Wurly EP1 FX
100	121	24	4	Wurly EP Tremolo
101	121	24	4	Wurly EP Tremolo FX
102	121	25	4	Wurly EP1 Chorus
103	121	1	4	Detuned EP1
104	121	2	4	Velocity EP1



105	121	13	4	Phase EP1
106	121	4	5	Phase EP2
107	121	14	4	Tremolo EP1
108	121	26	4	Tremolo EP2
109	121	15	4	Funk EP1
110	121	16	4	Modern EP1
111	121	17	4	Warm EP1
112	121	10	4	Fusion EP1
113	121	11	4	Club EP1
114	121	27	4	Club EP2
115	121	12	4	Jazz EP1
116	121	19	4	Wah EP1
117	121	0	5	DX E.Piano1
118	121	17	5	DX E.Piano2
119	121	18	5	DX E.Piano3
120	121	19	5	DX E.Piano4
121	121	20	5	DX E.Piano5
122	121	30	5	DX E.Piano6
123	121	31	5	DX E.Piano7
124	121	21	2	FM E.Piano
125	121	21	2	FM E.PianoFX
126	121	4	4	SA EP1
127	121	5	4	SA EP1 FX
128	121	5	5	SA EP2
129	121	6	5	SA EP2 FX
130	121	24	5	GS EP Dancer
131	121	24	5	GS EP Dancer FX
132	121	25	5	GS EP phase
133	121	26	5	GS EP soft
134	121	27	5	JD Crystal EP1
135	121	27	5	JD Crystal EP1 CH
136	121	28	5	JD Crystal EP2
137	121	28	5	JD Crystal EP2 CH
138	121	10	5	Tremolo EP2
139	121	11	5	Funk EP2
140	121	12	5	Modern EP2



141	121	13	5	Warm EP2
142	121	15	5	Wah EP2
143	121	29	5	Wah EP3
144	121	1	5	Detuned EP2
145	121	2	5	Velocity EP2
146	121	3	5	EP Legend
147	121	9	5	Mirror EP
148	121	0	7	Clavinet1
149	121	0	7	Clavinet1FX
150	121	10	7	Clavinet2
151	121	10	7	Clavinet2FX
152	121	11	7	Phase Clavinet
153	121	11	7	Phase ClavinetFX
154	121	12	7	Wah Clavinet1
155	121	12	7	Wah Clavinet1FX
156	121	14	7	Wah Clavinet2
157	121	14	7	Wah Clavinet2FX
158	121	15	7	Wah Clavinet3
159	121	15	7	Wah Clavinet3FX
160	121	13	7	E.Clavinet
161	121	0	8	Celesta1
162	121	10	8	Celesta2
163	121	11	8	Bright Celesta
164	121	12	8	Celesta&Sine
165	121	14	8	Celes&MusicBox
166	121	0	9	Glockenspiel1
167	121	10	9	Glockenspiel2
168	121	11	9	Glockenspiel&Sine
169	121	12	9	Glocken&Celesta
170	121	0	10	Music Box1
171	121	10	10	Music Box2
172	121	11	10	Music Box3
173	121	12	10	Toy Box
174	121	13	10	Music Box&Harp
175	121	14	10	Fantasia
176	121	14	10	Fantasia FX



177	121	0	11	Vibraphone1
178	121	0	11	Vibraphone1FX
179	121	12	11	SA Vibes
180	121	12	11	SA Vibes FX
181	121	10	11	SA Vibes Stereo
182	121	1	11	Vibraphone/Wide1
183	121	13	11	Vibraphone/Wide2
184	121	11	11	Two Vibes
185	121	14	11	Vibraphone&Bell
186	121	15	11	Vibra&Harpsic
187	121	16	11	Vibra&Strings1
188	121	17	11	Vibra&Strings2
189	121	0	12	Marimba1
190	121	10	12	Marimba2
191	121	15	12	Marimba3
192	121	16	12	Marimba Rep
193	121	1	12	Marimba/Wide
194	121	11	12	SinMarimba
195	121	12	12	Stereo Marimba
196	121	13	12	Marimba&Vibra
197	121	14	12	Wood Drum
198	121	0	13	Xylophone1
199	121	10	13	Xylophone2
200	121	11	13	Xylophone Rep
201	121	0	14	Tubular Bells
202	121	1	14	Church Bell1
203	121	3	14	Church Bell2
204	121	2	14	Carillon
205	121	0	15	Dulcimer
206	121	10	15	Zither
207	121	0	112	Tinkle Bell1
208	121	10	112	Tinkle Bell2
209	77	16	0	HA LowDrw F/S
210	77	16	1	HA LowDrw Cli F/S
211	121	0	18	RockOrgan Low F/S
212	77	16	2	HA Mid Drw F/S



213	77	16	3	HA Hi Drw F/S
214	77	16	14	HA LowDrw slow
215	77	16	15	HA LowDrw Cli slow
216	77	16	16	RockOrgan Low slow
217	77	16	17	HA Mid Drw slow
218	77	16	18	HA Hi Drw slow
219	77	16	4	HA Mixture1
220	77	16	5	HA Mixture2
221	77	16	6	HA Full Drw F/S
222	77	16	19	HA Full Drw slow
223	77	16	7	HA Perc 4'
224	77	16	8	HA Perc 2/23'
225	77	16	9	HA Perc 2'
226	77	16	10	HA Perc 4' shrt
227	77	16	11	HA Perc 2/23' shrt
228	77	16	12	HA Perc 2' shrt
229	77	16	13	HA KeyClick
230	121	2	16	60's Organ1
231	121	4	16	60's Organ2
232	121	5	16	60's Organ3
233	121	6	16	60's Organ4
234	121	7	16	60's Organ5
235	121	8	16	60's Organ6
236	121	9	16	60's Organ7
237	121	2	16	60's Ital Organ
238	121	17	16	60's Organ 2/23
239	121	18	16	60's Organ 1/35
240	121	25	16	60's Perc 4'
241	121	26	16	60's Perc 2/23'
242	121	27	16	70's Perc 4'
243	121	28	16	70's Perc 2/23'
244	121	29	16	Organ Guitar
245	121	32	16	ItaloDisco Organ1
246	121	33	16	ItaloDisco Organ2
247	121	0	17	Perc.Organ1
248	121	1	17	Detuned PercOrgan



249	121	2	17	M1Perc.Organ1
250	121	3	17	M1Perc.Organ2
251	121	4	17	M1Perc.Organ3
252	121	5	17	M1Perc.Organ4
253	121	0	19	Church Organ
254	121	1	19	ChurchOrg/Octave
255	121	2	19	Detune ChurchOrg
256	121	0	20	Reed Organ
257	121	0	16	Drawbar Organ1
258	121	3	16	Drawbar Organ2
259	121	1	16	Drawbar Organ det
260	121	10	16	Soft St DrawOrg
261	121	11	16	Mellow DrawOrg
262	121	13	16	Bright DrawOrg1
263	121	14	16	Bright DrawOrg2
264	121	10	17	70's PercOrgan1
265	121	13	17	70's PercOrgan2
266	121	11	17	Light Click Org1
267	121	12	17	Light Click Org2
268	121	10	18	Fast Rotary Organ
269	121	14	18	Slow Rotary Organ
270	121	11	18	Rock Organ2
271	121	12	18	Rotary Organ1
272	121	13	18	Rotary Organ2
273	121	1	20	Puff Organ
274	121	1	21	Holland Accordion1
275	121	2	21	Holland Accordion2
276	121	17	21	Rusian Accordion1
277	121	18	21	Rusian Accordion2
278	121	0	23	Tango Accordion1
279	121	10	23	Tango Accordion2
280	121	11	23	Tango Accordion3
281	121	10	21	Steirisches Acc.1
282	121	14	21	Steirisches Acc.2
283	121	12	21	Musette1
284	121	15	21	Musette2





285	121	16	21	Musette3
286	121	13	21	Accord It Solo
287	121	0	21	Accordion
288	121	11	21	Chorus Accordion
289	121	0	22	Harmonica1
290	121	11	22	Harmonica2 DX
291	121	10	22	Sweet Harmonica
292	121	12	22	Wah Harmonica
293	121	0	24	Nylon Guitar1
294	121	2	24	Nylon Guitar2
295	121	3	24	Nylon Guitar3
296	121	10	24	Velocity NylonGtr
297	121	11	24	Chorus NylonGtr
298	121	12	24	Bright NylonGtr
299	121	0	25	Steel Guitar1
300	121	10	25	Steel Guitar2
301	121	8	25	Steel Guitar3
302	121	4	25	Steel Guitar soft1
303	121	5	25	Steel Guitar bright1
304	121	6	25	Steel Guitar bright2
305	121	3	25	SteelGtr/BodySd
306	121	13	25	Velocity SteelGtr
307	121	16	25	Chorus SteelGtr
308	121	11	25	Tremolo SteelGtr1
309	121	12	25	Tremolo SteelGtr2
310	121	1	25	12Strings Guitar1
311	121	24	25	12Strings Guitar2
312	121	25	25	12Strings Guitar3
313	8	0	3	Hi String Guitar1
314	8	1	3	Hi String Guitar2
315	8	2	3	Hi String Mute Gtr
316	121	17	25	Nylon&SteelGtr
317	121	2	25	Mandolin1
318	121	14	25	Mandolin2
319	121	1	24	Ukulele
320	121	0	26	Jazz Guitar1



321	121	10	26	Jazz Guitar2
322	121	39	26	Jazz Guitar sld
323	121	12	26	Velocity JazzGtr
324	121	13	26	Octave JazzGtr
325	121	3	28	Jazz Man
326	121	1	26	Pedal Steel Guitar
327	121	18	25	HawaiianGuitar1
328	121	19	25	HawaiianGuitar2
329	121	11	26	Mellow Guitar
330	121	0	27	Clean Guitar1
331	121	6	27	Clean Guitar2
332	121	7	27	Clean Guitar3
333	121	8	27	Clean Guitar Trem
334	121	1	27	CleanGtr Chorus1
335	121	5	27	CleanGtr Chorus2
336	121	2	27	Mid Tone Guitar
337	121	0	28	Muted Guitar
338	121	1	28	Funk Guitar1
339	121	4	28	Funk Guitar2
340	121	2	28	Velocity MutedGtr
341	121	3	27	Vint Guitar1
342	121	4	27	Vint Guitar1 Trem
343	121	0	29	OverdrivenGtr1
344	121	10	29	OverdrivenGtr2
345	121	1	29	Guitar Pinch
346	121	0	30	DistortionGtr1
347	121	10	30	DistortionGtr2
348	121	5	30	DistortionGtr3
349	121	6	30	Lead Dist.Gtr1
350	121	7	30	Lead Dist.Gtr2
351	121	2	30	Rhythm DistGtr1
352	121	3	30	Rhythm DistGtr2
353	121	10	27	Stereo CleanGtr
354	121	11	27	Velocity CleanGtr
355	121	10	28	Delay MutedGtr.
356	121	11	28	Overdr.MutedGtr.



357	121	32	26	CountrySlide1
358	121	33	26	CountrySlide2
359	121	34	26	CountrySlide3
360	121	35	26	CountrySlide4
361	121	36	26	CountrySlide5
362	121	37	26	CountrySlide6
363	121	38	26	CountrySlide7
364	121	11	29	Dance Gtr1
365	121	12	29	Dance Gtr2
366	121	13	29	Dance Gtr3
367	121	14	29	Dance Gtr4
368	121	15	29	Dance Gtr5
369	121	16	29	Dance Gtr6
370	121	17	29	Dance Gtr7
371	121	18	29	Dance Gtr8
372	121	12	30	5th Distortion1
373	121	15	30	5th Distortion2
374	121	13	30	Octave DistGtr
375	121	14	30	Stereo DistGtr
376	121	1	30	Feedback Guitar1
377	121	11	30	Feedback Guitar2
378	121	1	31	Guitar Feedback
379	121	0	31	Guitar Harmonics1
380	121	65	25	Ac.Guitar FX
381	121	0	32	Acoustic Bass1
382	121	10	32	Acoustic Bass2
383	121	11	32	Acoustic Bass3
384	121	12	32	Detuned AcousBass
385	121	13	32	Filter AcousBass
386	121	15	32	AcoBass&MuteGtr
387	121	14	32	Jazz Style (Ride)
388	121	16	32	Rockabilly Bass
389	121	0	33	Finger Bass1
390	121	10	33	Finger Bass2
391	121	18	33	StingerBass1
392	121	19	33	StingerBass2



393	121	12	33	DarkFinger Stinger
394	121	11	33	Detuned FngrBass
395	121	1	33	Finger Slap Bass1
396	121	13	33	Finger Slap Bass2
397	121	14	33	Resonant FngrBass
398	121	15	33	Wah Finger Bass
399	121	16	33	Bass&DistortedGtr
400	121	0	34	Pick Bass1
401	121	10	34	Pick Bass2
402	121	14	34	Rock Pick Bass
403	121	11	34	Mute Pick Bass
404	121	12	34	Detuned Pick Bass
405	121	13	34	Bert's Bass
406	121	0	35	Fretless Bass1
407	121	10	35	Fretless Bass2
408	121	11	35	Fretless Bass3
409	121	13	35	Detuned Fretless 1
410	121	14	35	Detuned Fretless 2
411	121	15	35	Detuned Fretless 3
412	121	0	36	Slap Bass1
413	121	0	37	Slap Bass2
414	121	0	38	Synth Bass1
415	121	0	39	Synth Bass2
416	121	5	38	Synth Bass3
417	121	6	38	Synth Bass4
418	121	9	38	Synth Bass5
419	121	10	38	Synth Bass6
420	121	1	38	Warm Synth Bass1
421	121	13	38	Warm Synth Bass2
422	121	2	38	Reso SynBass1
423	121	7	38	Reso SynBass2
424	121	8	38	Reso SynBass3
425	121	11	38	80's Bass
426	121	12	38	90's Bass
427	121	18	38	Vain Bass1
428	121	3	38	Clavi Bass



429	121	4	38	Hammer
430	121	1	39	Lately Bass
431	121	2	39	FB Mono Bass
432	121	3	39	Attack Pulse
433	121	18	39	SineKickBass
434	121	10	39	Pulse Bass1
435	121	11	39	Pulse Bass2
436	121	12	39	Pulse Bass3
437	121	13	39	Pulse Bass4
438	121	14	39	Pulse Bass5
439	121	15	39	Pulse Bass6
440	121	16	39	Pulse Bass7
441	121	17	39	Pulse Bass Dist
442	121	17	33	Bass Guitar Slide
443	121	65	120	Syn Bass Slide
444	121	0	40	Violin1
445	121	11	40	Violin2
446	121	1	40	Slow Violin
447	121	10	40	The Violin
448	121	12	40	Mono Violin
449	121	13	40	Octave Violin
450	121	16	40	Two Violin
451	121	17	40	Soft Violin
452	121	18	40	Velocity Violin
453	121	15	40	Violin&Viola
454	121	0	41	Viola1
455	121	10	41	Viola2
456	121	11	41	Viola3
457	121	12	41	Dark Viola
458	121	0	42	Cello1
459	121	14	42	Cello2
460	121	0	43	Contrabass1
461	121	10	43	Contrabass2
462	121	13	48	Solo Strings
463	121	0	48	String Ensembles1
464	121	0	49	String Ensembles2



465	121	1	49	String Ensembles3
466	121	3	49	Smal Ensemble
467	121	2	48	60's Strings1
468	121	10	49	60's Strings2
469	121	3	48	Mtron Strings
470	121	14	49	Chamber Strings
471	121	15	48	Famous Marcatos
472	121	10	48	Stereo SlowStr
473	121	11	48	Slow Strings1
474	121	4	49	Slow Strings2
475	121	12	48	Legato Strings
476	121	14	48	Arco Strings
477	121	11	49	The Strings
478	121	0	44	Tremolo Strings1
479	121	10	44	Tremolo Strings2
480	121	11	44	Slow TremoloStr1
481	121	12	44	Slow TremoloStr2
482	121	2	49	Spiccato Strings
483	121	0	45	Pizzicato Ensemble1
484	121	2	45	Pizzicato Ensemble2
485	121	10	45	PizzicatoStr Solo
486	121	11	45	Octave Pizzicato
487	121	13	49	Orchestra1
488	121	12	49	70's Strings
489	77	91	0	Gladiator Strings
490	77	91	1	Mumien Strings
491	121	21	48	Strings&Horn1
492	121	22	48	Strings&Horn2
493	121	12	57	Strings&Tromb
494	121	1	48	Strings&Brass
495	121	0	50	Synth Strings1
496	121	0	50	Synth Strings1 Ch
497	121	0	51	Synth Strings2
498	121	0	51	Synth Strings2 Ch
499	121	1	50	Synth Strings3
500	121	1	50	Synth Strings3 Ch



501	121	10	51	Synth Strings4
502	121	10	51	Synth Strings4 Ch
503	121	10	50	Synth Strings5
504	121	10	50	Synth Strings5 Ch
505	121	0	52	Choir Aahs1
506	121	1	52	Choir Aahs2
507	121	10	52	Choir Aahs3
508	121	11	52	Choir Aahs4
509	121	0	53	Voice Oohs
510	121	1	53	Humming
511	77	91	16	Halleluja Choir1
512	77	91	17	Halleluja Choir2
513	121	1	54	Analog Voice1
514	121	10	54	Analog Voice2
515	121	0	54	Synth Voice
516	121	12	52	Mellow Choir
517	121	13	52	Stereo Choir Aahs
518	121	14	52	Strings&Choir1
519	121	15	52	Strings&Choir2
520	121	0	55	Orchestra Hit
521	121	10	55	Octave OrchHit
522	121	1	55	80sHit
523	121	2	55	6th Hit
524	121	0	46	Orchestral Harp1
525	121	10	46	Orchestral Harp2
526	121	1	46	Yang Chin
527	121	0	56	Trumpet1
528	121	10	56	Trumpet2
529	121	1	56	DarkTrump Soft1
530	121	11	56	DarkTrump Soft2
531	121	2	56	2 Trumpets
532	121	0	59	Muted Trumpet1
533	121	1	59	Muted Trumpet2
534	121	10	59	Muted Trumpet3
535	121	11	59	Muted Trumpet4
536	121	13	56	Hi Solo Trumpet



537	121	14	56	Wah Trumpet
538	121	0	57	Trombone1
539	121	1	57	Trombone2
540	121	2	57	Bright Trombone
541	121	10	57	Dark Trombone1
542	121	0	60	FrenchHorn Sec1
543	121	12	60	FrenchHorn Sec2
544	121	1	60	French Horn1
545	121	10	60	French Horn2
546	121	11	60	French Horn3
547	121	0	58	Tuba1
548	121	10	58	Tuba2
549	121	11	58	Tuba3
550	0	113	58	Bariton
551	121	12	58	Bariton&Bass
552	121	13	58	Soft Tuba
553	121	0	61	Brass Section1
554	121	9	61	Brass Section1 Oct
555	121	1	61	Brass Section2
556	121	10	61	Brass Section3
557	121	11	61	Brass Section4
558	121	23	61	SA Brass1
559	121	24	61	SA Brass2
560	121	14	61	Bright Brass
561	121	21	61	Club Brass
562	121	15	61	Dark Brass2
563	121	13	61	Brassband
564	121	16	61	Mute BrassEns
565	121	17	61	Sforzato Brass
566	121	13	60	Fifth HornOrch
567	121	0	62	Synth Brass1
568	121	0	62	Synth Brass1 Ch
569	121	0	63	Synth Brass2
570	121	0	63	Synth Brass2 Ch
571	121	1	62	Synth Brass3
572	121	1	62	Synth Brass3 Ch





573	121	1	63	Synth Brass4
574	121	1	63	Synth Brass4 Ch
575	121	3	63	Synth Brass5
576	121	3	63	Synth Brass5 Ch
577	121	2	62	Analog SynBrass1
578	121	2	62	Analog SynBrass1 Ch
579	121	2	63	Analog SynBrass2
580	121	2	63	Analog SynBrass2 Ch
581	121	4	63	Analog SynBrass3
582	121	4	63	Analog SynBrass3 Ch
583	121	5	63	Analog SynBrass4
584	121	5	63	Analog SynBrass4 Ch
585	121	10	62	Octave SynBrass
586	121	10	62	Octave SynBrass Ch
587	121	11	63	Echo Brass
588	121	3	62	Jump Brass
589	121	4	62	Mega Jump Brass
590	121	11	69	Analog Horns
591	121	12	62	P5 Brass1
592	121	13	62	P5 Brass2
593	121	14	62	P5 Brass3
594	121	17	62	Munich Solo Brass
595	121	18	62	Munich Brass
596	121	15	62	P5 Tuba1
597	121	16	62	P5 Tuba2
598	121	18	61	Brass&Strings1
599	121	10	63	Brass&Strings2
600	121	21	57	Trombone&Str
601	121	11	62	SynBrass&Strings1
602	121	21	56	3Trumpets Loose
603	121	21	59	3MuteTrump Loose
604	121	22	61	Brass&Wood
605	121	0	64	Soprano Sax1
606	121	10	64	Soprano Sax2
607	0	117	64	Soprano Sax3
608	121	11	64	Soprano Sax Soft



609	121	12	64	Slow Soprano Sax
610	121	13	64	Sweet Soprano Sax
611	121	0	65	Alto Sax1
612	121	10	65	Alto Sax2
613	0	117	65	Alto Sax3
614	121	11	65	Soft Alto Sax
615	121	0	66	Tenor Sax1
616	121	10	66	Tenor Sax2
617	0	117	66	Tenor Sax3
618	121	0	67	Baritone Sax1
619	121	10	67	Baritone Sax2
620	121	11	67	Soft Baritone Sax
621	121	13	65	Sax Band1
622	121	14	65	Sax Band2
623	121	15	65	Sax Band3
624	121	16	65	Sax Band4
625	121	17	65	Sax Band5
626	121	18	65	Sax Band6
627	121	19	65	Sax Band7
628	121	0	68	Oboe1
629	121	10	68	Oboe2
630	121	11	68	Sweet Oboe
631	121	0	69	English Horn1
632	121	10	69	English Horn2
633	121	0	70	Bassoon1
634	121	10	70	Bassoon2
635	121	0	71	Clarinet1
636	121	10	71	Clarinet2
637	121	11	71	BassClarinet
638	121	12	71	SoloClarinet
639	121	0	72	Piccolo1
640	121	10	72	Piccolo2
641	121	0	73	Flute1
642	121	10	73	Flute2
643	121	11	73	Sweet Flute
644	121	0	74	Recorder1



645	121	10	74	Recorder2
646	121	0	75	Pan Flute
647	121	10	75	Sweet Pan Flute
648	121	12	75	Dark Pan Flute
649	121	0	76	Blown Bottle
650	121	0	77	Shakuhachi1
651	121	0	78	Whistle
652	121	0	79	Ocarina1
653	121	10	79	Ocarina2
654	121	12	69	Woodwinds
655	77	93	0	Rhy-Synth 01
656	77	93	1	Rhy-Synth 02
657	77	93	2	Rhy-Synth 03
658	77	93	3	Rhy-Synth 04
659	77	93	4	Rhy-Synth 05
660	77	93	5	Rhy-Synth 06
661	77	93	6	Rhy-Synth 07
662	77	93	7	Rhy-Synth 08
663	77	93	8	Rhy-Synth 09
664	77	93	9	Rhy-Synth 10
665	77	93	10	Rhy-Synth 11
666	77	93	32	MegaSynth1
667	77	94	0	Plucked Higher1
668	77	94	1	Plucked Strings1
669	77	94	2	Plucked Shape
670	77	95	0	90s Saw1
671	77	95	1	90s Saw2
672	77	95	2	90s Saw Oct1
673	77	95	3	90s Saw Oct2
674	77	95	4	90s Dance Synth1
675	77	95	5	90s Dance Synth2
676	77	95	6	90s Dance Synth3
677	77	95	32	90s TechnoStab1
678	77	95	33	90s TechnoStab2
679	77	95	34	90s TechnoBass1
680	77	95	35	90s TechnoBass2



681	77	95	16	Arp Saw1
682	77	95	17	Arp Saw2
683	77	95	18	Arp Saw3
684	77	95	19	Arp Saw4
685	77	95	20	Arp Saw5
686	77	95	21	Arp Saw6
687	77	95	22	Arp Saw7
688	77	95	23	Arp Saw8
689	77	95	99	Technolot
690	121	0	80	Square Lead1
691	121	1	80	Square Lead2
692	121	2	80	Sine Lead
693	121	33	80	Jp Lead1
694	121	34	80	Jp Lead2
695	121	35	80	Jp Lead3
696	121	36	80	Pulse Lead1
697	121	37	80	Pulse Lead2
698	121	38	80	Pulse Lead3
699	121	39	80	Pulse Lead4
700	121	40	80	Pulse Lead5
701	121	42	80	Cartoon Jump
702	121	41	80	Pulsar
703	121	0	81	Sawtooth1
704	121	1	81	Sawtooth2
705	121	2	81	Sawtooth&Pulse
706	121	3	81	Double Sawtooth
707	121	4	81	Sequenced analog
708	121	0	82	Calliope
709	121	12	82	SynCalliope Soft
710	121	0	83	Chiffer Lead1
711	121	10	83	Chiffer Lead2
712	121	11	83	Chiffer Lead3
713	121	0	84	Charang Lead
714	121	1	84	Wire Lead1
715	121	2	84	Wire Lead2
716	121	11	84	Wire Lead3



717	121	0	85	Voice Lead1
718	121	10	85	Voice Lead2
719	121	0	86	Fifths Lead
720	121	10	86	5th SawWave
721	121	0	87	Bass&Lead
722	121	1	87	Soft wr1
723	121	10	80	Square
724	121	11	80	Slow Square Lead
725	121	12	80	JP Sine Solo
726	121	19	80	JP Puls Solo
727	121	13	80	Square Lead3
728	121	14	80	Thick Square
729	121	15	80	Popcorn
730	121	16	80	Quint1
731	121	18	80	Quint2
732	121	17	80	2Oscillators Lead
733	121	10	81	Wavy Sawtooth
734	121	11	81	Super Analog
735	121	12	81	Big Lead
736	121	13	81	Double Lead
737	121	14	81	FilterModLead1
738	121	15	81	FilterModLead2
739	121	10	82	PWM 4th
740	121	11	82	Minor Chord
741	121	10	87	Massiness
742	121	11	87	Delayed Lead2
743	121	12	87	Delayed Lead3
744	121	25	80	Funny1
745	121	26	80	Funny2
746	121	27	80	Funny3
747	121	28	80	Funny4
748	121	29	80	Funny5
749	121	32	88	Dig.Native Dance1
750	121	33	88	Dig.Native Dance2
751	121	34	88	Native Pad1
752	121	35	88	Native Pad2



753	121	36	88	Native Pad3
754	121	37	88	Native Pad4
755	121	38	88	Native Pad5
756	121	39	88	Native Pad6
757	121	40	88	Chorale Pad
758	121	0	88	New age Pad1
759	121	10	88	New Age Pad2
760	121	11	88	New Age Pad3
761	121	13	88	New Year Pad
762	121	0	89	Warm Pad1
763	121	10	89	Warm Pad2
764	121	1	89	Sine Pad
765	121	11	89	PWM Pad
766	121	12	89	Warmly Pad
767	121	13	89	Horn Pad
768	121	0	90	Poly Synth1
769	121	10	90	Poly Synth2
770	121	14	90	Poly Synth3
771	121	0	91	Choir Pad
772	121	1	91	Itopia Pad
773	121	0	92	Bowed Pad
774	121	0	93	Metallic Pad1
775	121	10	93	Metallic Pad2
776	121	0	94	Halo Pad1
777	121	10	94	Halo Pad2
778	121	11	94	Halo Pad3
779	121	0	95	Sweep Pad1
780	121	10	95	Sweep Pad2
781	121	10	85	Soft Vox
782	121	10	91	Space Voice
783	121	11	90	Click Pad
784	121	12	90	Analog Pad
785	121	13	90	Poly Pad
786	121	13	92	Wale Pad
787	121	10	92	Bowed Pad2
788	121	11	92	Bowed Pad3



789	121	11	93	Pan Pad1
790	121	12	93	Pan Pad2
791	121	11	95	Dipolar Pad
792	121	12	95	Rising
793	121	14	89	Mix Pad1
794	121	15	89	Mix Pad2
795	121	16	89	Mix Pad3
796	121	17	89	Mix Pad4
797	121	18	89	Mix Pad5
798	121	19	89	Mix Pad6
799	77	89	0	Warm Pad1 NV
800	77	89	16	Strings1 NV
801	77	89	24	Synth String1 NV
802	77	89	32	Org1 NV
803	77	89	33	Org2 NV
804	77	89	34	Org3 NV
805	77	89	35	Italo Organ NV
806	77	95	64	HP Reso Pad1
807	77	95	65	HP Reso Pad2
808	77	95	66	HP Reso Pad3
809	77	95	67	HP Reso Pad4
810	77	95	68	LP Reso Pad1
811	77	95	69	LP Reso Pad2
812	77	95	70	LP Reso Pad3
813	77	95	71	LP Reso Pad4
814	77	95	72	HPLP Pad1
815	77	95	97	Analog Choir
816	77	95	98	Analog Male Solo
817	121	0	96	Rain Heaven
818	121	0	97	SoundTrack
819	121	0	98	Crystal1
820	121	10	98	Crystal2
821	121	1	98	Synth Mallet
822	121	0	99	Atmosphere1
823	121	1	99	Atmosphere2
824	121	10	99	Warm Air



825	121	0	100	Brightness
826	121	10	100	Smog
827	121	0	101	Goblins
828	121	10	101	Goblin 2
829	121	11	101	Choir Bell1
830	121	12	101	Choir Bell2
831	121	13	101	Synth Harpsi Bell
832	121	0	102	Echoes
833	121	1	102	Echo bell1
834	121	11	102	Echo bell2
835	121	2	102	Echo pan
836	121	10	102	Echo Drops
837	121	0	103	Sci-Fi1
838	121	10	103	Sci-Fi2
839	121	0	104	Sitar1
840	121	1	104	Sitar2 Bend
841	121	10	104	Sitar&Strings 1
842	121	11	104	Sitar&Strings 2
843	121	0	105	Banjo1
844	121	10	105	Banjo2
845	121	0	106	Shamisen1
846	121	10	106	Shamisen2
847	121	0	107	Koto1
848	121	10	107	Koto2
849	121	1	107	Taisho Koto1
850	121	11	107	Taisho Koto2
851	121	12	107	Taisho Koto3
852	121	0	108	Kalimba1
853	121	10	108	Kalimba2
854	121	0	109	Bag Pipe1
855	121	10	109	Bag Pipe2
856	121	0	110	Fiddle1
857	121	10	110	Fiddle2
858	121	0	111	Shanai1
859	121	10	111	Shanai2
860	121	0	47	Timpani1





861	121	10	47	Timpani2
862	121	11	47	Timpani3
863	121	0	113	Agogo1
864	121	10	113	Agogo2
865	121	11	113	CowBell 88
866	121	0	114	Steel Drums1
867	121	10	114	Steel Drums2
868	121	0	115	Woodblock1
869	121	10	115	Woodblock2
870	121	1	115	Castanets1
871	121	11	115	Castanets2
872	121	0	116	Taiko Drum1
873	121	10	116	Taiko Drum2
874	121	2	116	Tribal Break1
875	121	3	116	Tribal Break2
876	121	1	116	ConBass Drum1
877	121	11	116	ConBass Drum2
878	121	12	116	ConBassBD&CR1
879	121	13	116	ConBassBD&CR2
880	121	120	116	Sub Bomb
881	121	16	116	BD Eight O Eight1
882	121	17	116	BD Eight O Eight2
883	121	18	116	BD Nine O Nine1
884	121	19	116	BD Nine O Nine2
885	121	20	116	BD Nine O Nine3
886	121	21	116	EDM Kick1
887	121	22	116	EDM Kick2
888	121	0	117	Melodic Tom
889	121	1	117	Power Melodic Tom
890	121	16	117	Rodger's Tom1
891	121	17	117	Rodger's Tom2
892	121	18	117	Rodger's Tom3
893	121	19	117	Rodger's Tom4
894	121	20	117	Roto-Tom
895	121	0	118	Synth Drum
896	121	1	118	Rhythm Box Tom



897	121	2	118	Electric Drum1
898	121	10	118	Electric Drum2 MT
899	121	3	118	70s Synth Drum1
900	121	4	118	70s Synth Drum2
901	121	5	118	70s Synth Drum3
902	121	6	118	70s Synth Drum4
903	121	11	118	PWL Toms Stereo
904	121	90	118	Rev Tom1
905	121	91	118	Rev Tom2
906	121	92	118	Rev Tom3
907	121	16	118	SD Nine O Nine1
908	121	17	118	SD Nine O Nine2
909	121	18	118	SD Nine O Nine3
910	121	19	118	SD Nine O Nine4
911	121	20	118	SD Eight O Eight1
912	121	21	118	SD Eight O Eight2
913	121	80	118	EDM Break SD
914	121	22	118	RevSD NineONine1
915	121	23	118	RevSD NineONine2
916	121	24	118	RevSD NineONine3
917	121	25	118	RevSD NineONine4
918	121	26	118	RevSD EightOEight1
919	121	27	118	RevSD EightOEight2
920	121	127	118	VL-1 Kick
921	121	126	118	Rev VL-1 Kick
922	121	0	119	Reverse Cymbal1
923	121	10	119	Reverse Cymbal2
924	121	11	119	Reverse Cymbal3
925	121	12	119	Reverse Cymbal4
926	121	13	119	Reverse Kick1
927	121	14	119	Reverse Kick2
928	121	15	119	Reverse High Q
929	121	24	119	Kick-Crash1
930	121	25	119	Kick-Crash2
931	121	26	119	Kick-Crash3
932	121	27	119	Crash1



933	121	28	119	Crash2
934	121	120	119	Reverb Clap1
935	121	121	119	Reverb Clap2
936	121	122	119	Reverb Clap3
937	121	123	119	Nine O Nine Clap
938	121	124	119	Eight O Eight Clap
939	121	125	119	House Clap&SD1
940	121	126	119	House Clap&SD2
941	121	110	119	Reverse Clap1
942	121	111	119	Reverse Clap2
943	121	112	119	Reverse Clap3
944	121	113	119	Reverse Clap4
945	121	127	6	WhiteNoise HH1
946	121	127	7	WhiteNoise HH2
947	121	127	8	WhiteNoise Cymbal
948	121	32	120	Laser Synth1
949	121	33	120	Laser Synth2
950	121	32	122	Synth Lifter1
951	121	33	122	Synth Lifter2
952	121	0	120	Guitar Fret Noise
953	121	1	120	Gtr Cutting Noise
954	121	2	120	AcBass String Slap
955	121	3	120	Ac.Gtr Cutting Noise
956	121	4	120	Echolot1
957	121	5	120	Echolot2
958	121	6	120	Echolot3
959	121	0	121	Breath Noise
960	121	1	121	Flute Key Click
961	121	10	121	Breath Noise2
962	121	11	121	Flute Key Click2
963	121	0	122	Seashore
964	121	1	122	Rain
965	121	2	122	Thunder
966	121	3	122	Wind
967	121	6	122	NoiseSweep1
968	121	7	122	NoiseSweep1 128



969	121	8	122	NoiseSweep1 128St
970	121	9	122	NoiseSweep Velo
971	121	11	122	NoiseSweep2
972	121	12	122	NoiseSweep2 128
973	121	10	122	Ana-Melolifter1
974	121	64	122	Pink Noise
975	121	65	122	White Noise
976	121	0	123	Bird Tweet
977	121	0	124	Telephone Ring1
978	121	1	124	Telephone Ring2
979	121	4	124	Scratch
980	121	5	124	Wind Chime
981	121	0	125	Helicopter
982	121	5	125	Siren1
983	121	6	125	Siren2
984	121	0	126	Applause
985	121	3	126	Punch
986	121	4	126	Heart Beat
987	121	0	127	Gunshot
988	121	3	127	Explosion
989	121	21	16	Organ&StStrings
990	121	21	18	RockOrg&Strings
991	121	21	19	ChurchOrg&Choir
992	121	22	19	ChurchOrg&Str
993	121	22	22	Harmonica&Str
994	121	23	25	SteelGtr&WarmPd
995	121	23	48	Orchestra 2
996	121	23	49	Symphonic
997	121	21	52	Choir&Str
998	121	21	68	Wood&Strings
999	121	21	71	Woods Small
1000	121	21	75	PanFlute&StrPad
1001	120	0	0	Standard1
1002	120	0	1	Standard2
1003	120	0	2	Pop
1004	120	0	8	Room1



1005	120	0	16	Power1
1006	120	0	17	Power2
1007	120	0	24	Electro1
1008	120	0	25	Analog1
1009	120	0	23	VL-1
1010	120	0	32	Jazz
1011	120	0	40	Brush
1012	120	0	48	Symphonic
1013	120	0	70	Dance
1014	120	0	81	House
1015	120	0	71	Funk
1016	120	0	72	Rock
1017	120	0	73	Latin
1018	120	0	43	Percussion
1019	120	0	57	Claps&Percussion
1020	120	0	75	PopSchlager1
1021	120	0	26	PopSchlager2
1022	120	0	77	Soul
1023	120	0	46	EDM
1024	120	0	95	80s Pop1
1025	120	0	96	80s Pop2
1026	120	0	97	80s Pop3
1027	120	0	105	80s Rock1
1028	120	0	106	80s Rock2
1029	120	0	107	80s Rock3
1030	120	0	111	Phil's Drums1
1031	120	0	112	Phil's Drums2
1032	120	0	115	80s Dance1
1033	120	0	116	80s Dance2
1034	121	127	127	Midi



zusätzlich 14 XG Drumkits für Midi Kompatibilität